Fontaine by ITALIA

ULTIME

Vessel Sink Filler Faucet | Single Post Bathroom Faucet



MFF-UTMVF
MFF-UTMVFD



MFF-UTMC1
MFF-UTMC!D

INSTALLATION

Tools:

- Adjustable Wrench
- Pliers
- Pipe Wrench
- Screwdriver
- Teflon Tape

1



Shut off water supplies. Remove old faucet. Clean sink surface in preparation for new faucet.

2



Set new faucet into hole of the sink .

3



Secure to sink by installing rubber washer (2) , steel washer (3) & nut (4) onto mounting stud (1),tighten with wrench.

4



Apply pipe tape onto threads of water supplies.Use wrench when tightening the hose, do not overtighten.

5



IMPORTANT: Remove aerator, turn on the hot and cold angle valve(4) and turn faucet handle (1) all the way on for one minute. Check all connections at arrows for leaks. Re-tighten if necessary, but do not overtighten.

Maintenance:

Your new Lavatory faucet is designed for years of trouble-free performance.
Keep it looking new by cleaning it periodically with a soft cloth. Avoid abrasive cleaners, steel wool and harsh chemicals as these will dull the finish and void your warranty.